



118/50 mm (± 10%)

151 LG 04

**UNIVERSALE
BALAY - NEW POL
FAGOR**

1 Livello - Tubetto centrale
o laterale
1 Level - Central or lateral
pipe




118/50 - 135/90 (±10%)

152 LG 07

**UNIVERSALE
STANDARD**

2 Livelli - 2 Levels




183/81 mm (± 10%)

151 LG 05

**UNIVERSALE
FAGOR - BALAY**

1 Livello - Tubetto centrale
o laterale
1 Level - Central or lateral
pipe



151 AR 00

ARISTON MERLONI


Cod. orig. 008677
1 Livello - 1 Level
LB100 - 120 - 410 - 412 - 420
AR 1070CD - 1170CD -
970CD
890CD - 900CD - 1218CD



151 LG 06

**UNIVERSALE
VARI USI**

1 Livello - 1 Level
Sostituisce tutti i vecchi modelli
Can change all old models



151 AR 01

ARISTON MERLONI

Cod. orig. 020187
1 Livello - 1 Level
AR 412 - 414 - 424 - 425 - 434
AR 456TX - 466TX - 470TX -
544TX
AR 473 - 836 - 846 - 876

205/95 mm (±10%)



105/65 mm (±10%)

151 LG 07

**BALAY
BOSCH
UNIVERSALE**

Copreci 4 contatti/contact



151 AR 02

ARISTON MERLONI

Cod. orig. 041095
1 Livello - 1 Level
New Aristella




120/85 - 180/90 mm (±10%)

152 LG 05

**UNIVERSALE
VARI USI**

2 Livelli - 2 Levels
Sostituisce tutti i vecchi modelli
Can change all old models



152 AR 00

ARISTON MERLONI

Cod. orig. 019750
2 Livelli - 2 Levels
646TX - 656TX - 658TX -
668TX - 670 TX - 676TX -
720TX




125/90 - 160/110 mm (±10%)

152 LG 06

**UNIVERSALE
VARI USI**

2 Livelli - 2 Levels
Sostituisce tutti i vecchi modelli
Can change all old models
7 contatti - 7 contact
Antitrabocco 280 mm



152 AR 01

ARISTON MERLONI

Cod. orig. 041094
2 Livelli - 2 Levels
New Aristella



62/22 - 77/39 - 90/55

152 BY 00

**BALAY
BOSCH - SIEMENS
LYNX**

3 Livelli - 3 Level



151 SL 00

SILTAL


Cod. orig. 49567900
4 contatti - 4 contact
Livello/level 135/70/350



151 CY 00

CANDY

ELBI - 3 contatti



151 ZN 00

**ZANUSSI
REX**


Cod. orig. 50657569005
1 Livello - 1 Level
Lavastoviglie - Dishwasher



151 CY 01

CANDY

ELBI - 4 contatti



151 ZN 01

**ZANUSSI
REX**


Cod. orig. 50209437008
1 Livello - 1 Level
Lavastoviglie - Dishwasher



151 CY 02

**CANDY
ZEROWATT
GIAS**


Cod. orig. 92744580
4 contatti - 4 contact
Con tasto 1/2 carico
Botton 1/2 charge



152 ZN 00

**ZANUSSI
REX**

Cod. orig. 50223286001
2 Livelli - 2 Levels




240/110 - 440 mm

151 CY 03

**CANDY
ZEROWATT
GIAS**


Cod. orig. 91204594
4 contatti - 4 contact
Antitrabocco 440 mm



152 ZN 01

**ZANUSSI
REX**

Cod. orig. 50209631006
3 Livelli - 3 Levels



152 ID 00

INDESIT

Cod. orig. 108946
2 Livelli - 2 Levels
New Line



152 ZN 02

**ELECTROLUX
ZANUSSI
REX**

Cod. orig. 1502035007
Tubetto centrale - Central pipe
Lavastoviglie - Dishwasher